

FIG. 1

200

INSTRUMENT	PRIORITY
SLIDE GUITAR	1
SLAP BASS	2
VIOLIN	3
PIANO	4
CONGAS	5
COWBELL	6
SHAKER	7
XYLOPHONE	8
TIMPANI	9

↔ POLYPHONY AVAILABLE
IN MIDI DEVICE =8

FIG. 2





FIG. 3



400

FIG. 4